

INSTALLATION INSTRUCTIONS

Part# T92498-1 (Chrysler - Ball on shaft)

Shift Cable Repair End (Grommet)

Fits: ('05-'15) Chrysler, Dodge & Jeep
with 41TE or 62TE Transmission

1. Determine the cable end that you have.
(Fig. 1 & 2)
2. If you have a cable with a clip that protrudes past the edges of the housing (Fig. 1) then simply remove the old clip & go to step 4.
3. If you have a cable with a clip the resides inside of the housing (Fig. 2), use a 13/32" drill bit to drill out the old clip. This also enlarges the hole (Fig. 3)
NOTE: Do NOT drill out the cable shown in (Fig 1)
4. Next snap the T92498-1 into the cable & reattach the cable onto the shifter arm (Fig. 4)
5. Check to insure that the cable is secure.



FIG. 1



FIG. 3



FIG. 2



FIG. 4

Teckpak Hotline: 1-800-527-2544
www.teckpak-fitall.com